




## RADAR GUN RS232 INTERFACE INSTALLATION GUIDE


### FOR DECATUR HUNTER, GENESIS I & II, AND TARGETRON RAPIDFIRE:

The VSI+ interfaces with these radar guns' RS232 port; therefore installation is relatively simple, provided the radar gun is programmed to Output Data, which is the factory default. If the radar gun's programming has been changed, the VSI must be set to match that of the new programming. Then construct the cable for connection using the following pin out diagrams:

#### Decatur Hunter & Genesis I & II:



#### Targetron Rapidfire:



See the VSI+ Operations Manual for programming of the on-screen display.

**Note:** if the VSI+ is set to auto Baud, it should automatically select the proper Baud rate, but if the data does not appear, go into the VSI communications menu and manually set the Baud rate to 1200.

**American Video Equipment**

1617 E. RICHEY ROAD • HOUSTON, TEXAS, 77073 • TEL:(713)443-2300 FAX: (713)443-8915